LTECH

LT-851-5A **DMX-PWM CV DECODER**













LT-851-5A DMX-PWM decoder works to convert universal DMX512 digital signal to PWM signal, which controlled by DMX512 console, with 8bit gray scale output per channel. Realize 0-100% brightness and various changing effect. And can control single color, two color, RGB LED lights.

1. Product Parameter:

LT-851-5A

Input Signal: DMX512 Working Temp.: -30 °C ~65 °C

 Input Voltage: 5~24Vdc Dimensions: L175×W42×H33mm

 Max Current Load: 5A×3CH Max 15A • Package Size: L183×W48×H41mm

Max Output Power: 75W/180W/360W(5V/12V/24V)
Weight(G.W.): 310g

• DMX512 Socket: Green Terminal

Configuration Diagram:





3. Dip Switch Operation:



3.1 How to set DMX address via dip switch:

FUN=OFF (the 10th dip switch=OFF) **DMX Mode**

DMX address value=the total value of (1-9), to get the place value when in "on" position, otherwise will be 0.

E.g.1: Set Initial Address To 32. E.g.2: Set Initial Address To 37. E.g.3: Set Initial Address To 178.




* When Dip switch 1-9 are OFF, the defaulted initial DMX address is 1.

3.2 Self-testing Mode:

FUN=ON (the 10th dip switch=ON) Self-testing Mode


Dip Switch	1-9=off	1=on	2=on	3=on	4=on	5=on	6=on	7=on	8=on	9=on
Self-test Function									7 Colors Jumping	



For changing effects (Dip Switch 8/9=on): DIP switch 1-7 is used to realize 7 speed levels. (7=on, the fastest level)

[Attn] When several dip switches are on, subjected to the highest switch value. As the figure above shows, the effect will be 7 colors smooth at 7 speed level.

4. Wiring Diagram:



- An amplifier is needed when more than 32 decoders are connected, signal amplification should not be more than 5 times continuously.
- If the recoil effect occurs because of longer signal line or bad line quality, please try to connect 0.25W 90-120Ω terminal resistor at the end of each line.

5. Attention:

- 5.1 The product shall be installed and serviced by the qualified person.
- 5.2 This product is non-waterproof. Please avoid the sun and rain. When installed outdoors please ensure it is mounted in a water proof enclosure.
- 5.3 Good heat dissipation will prolong the working life of the controller. Please ensure good ventilation.
- 5.4 Please check if the output voltage of the LED power supplies used comply with the working voltage of the product.
- 5.5 Please ensure that adequate sized cable is used from the controller to the LED lights to carry the current. Please also ensure that the cable is secured tightly in the connector.
- 5.6 Ensure all wire connections and polarities are correct before applying power to avoid any damages to the LED lights.
- 5.7 If a fault occurs please return the product to your supplier. Do not attempt to fix this product by yourself.

6. Warranty Agreement:

- 6.1 We provide lifelong technical assistance with this product:
- A 1-year warranty is given from the date of purchase.
- 6.2 Warranty exclusions below:
 - Any man-made damages caused from improper operation, or connecting to excess voltage and overloading.
 - The product appears to have excessive physical damage.
 - Damage due to natural disasters and force majeure.
 - Warranty label, fragile label and unique barcode label have been damaged.
- The product has been replaced by a brand new product.
- 6.3 Repair or replacement as provided under this warranty is the exclusive remedy to the customer. We shall not be liable for any incidental or consequential damages for breach of any stipulation in this warranty.
- 6.4 Any amendment or adjustment to this warranty must be approved in writing by our company only.
- ★ This manual only applies to this model. We reserve the right to make changes without prior notice.