

CONNECTION GUIDE

1 Wire Solderless Snap Down T Connectors



1.) Firmly insert your 18-24AWG wires through the wire hole guides and over the conductive metal blades.



2.) Using a pair of pliers firmly snap the connector top down. The small red tabs on the bottom will click into place.



3.) Clamp both sides of the connector and test continuity.