CONNECTION INSTRUCTIONS Receiver for WiFi-104 Controller, 5-24VDC 5A/CH






5-24VDC INPUT Input from 5-24VDC power supply

Top View of Wireless Receiver

RoHS

(€ F©

Maximum Output 5A x 4CH Max Output 12VDC-240W Max 24VDC-480W Max



Single Channel Output 5A x 1CH Max Output 12VDC-60W Max

WiFi-104 Zone Receiver Pairing Guide: LC-LT-RGBW-RC





- Apply 5-24VDC power to your WiFi-104 Controller.
- Connect to the WiFi-104 through your WiFi phone or tablet settings.
- Open the WiFi104 app and choose the "Zone" button from the active controller in your Device





- Activate the zone you wish to pair by sliding the "LINK" toggle button to the right until it turns green
- Note: WiFi-104 Controller will always act as Zone 1.
- Rename your zones by touching the zone name.
- Choose the control type by touching zone type.



RGB

RGBW

Cancel



- Choose the proper control type for the zone you wish
- Note: Default control type is RGBW.





- Activate any additional Zone(s) that you wish to
- Press the Back button in the upper left hand corner of your screen to get back to your Device List.






- From your Device List, click on the controller that you wish to pair your receivers to





- Select the zone that you wish to pair your receiver
- Selected zone will be highlighted in blue.





5-24VDC Power

- With 5-24VDC power applied to your receiver, press the black "RUN" button and let go.
- The red indicator light will turn from flashing red to solid red.
- Note: To clear pairing, press and hold "RUN" button until you hear a long beep.





- Immediately after, press anywhere within the color palette selection in your WiFi104 app.
- A beep from the receiver will indicate a successful pairing.
- -The red "RUN" indicator light on your receiver will return to flashing.





- Repeat steps 1-8 for any additional receiver(s) that you wish to pair.
- In the "Group" tab at the bottom of your app you can choose to control multiple zones over 3 groups.
- Choose the zones you want to group, add a group name and toggle the slider to the right to activate.



