ADDRESS SETTING
Use this button to pair
Receiver to WiFi Controller

Top View of Wireless Receiver

Maximum Output
5A x 4CH Max Output
12VDC-240W Max
24VDC-480W Max

LED CONTROLLER
MODEL:R4-5A
2.5G WIRELESS REMOTE CONTROL
POWER INPUT: DC5V-DC24V
OUTPUT: 5A x 4CH
CE FC RoHS

5-24VDC INPUT
Input from 5-24VDC
power supply

Single Channel Output
5A x 1CH Max Output
12VDC-60W Max
24VDC-120W Max

UX8 and WiFi-104 Pairing Guide

1
- Apply 5-24VDC power to your WiFi-104 Controller.
- Connect to the WiFi-104 through your WiFi phone or tablet settings.
- Download WiFi104 app.

2
- Open WiFi104 app.
- If WiFi-104 doesn't show up in device list hit the blue search icon.
- Once the device is seen press the controller to get to the control screen.

3
- Apply 5VDC Power to your UX8 controller.
- Press and hold the power button for 3+ seconds.
- All indicator lights will flash blue.

4
- Within 5 seconds press the color area in the WiFi104 App.

5
- The UX8 will beep, the indicator lights will stop flashing and go back to normal function.

6
- Pair receivers to UX8.
- With 5-24VDC power applied to your receiver, press the black "RUN" button and let go.
- The red indicator light will turn from flashing red to solid red.

5-24VDC Power

7
-Immediately press and hold the zone number on the UX8 that you wish to pair, a long beep signifies a successful pair.
-Repeat for additional receivers.

8
- Go back to device list and enter the zone setup.

9
- Activate your zones according to the paired receivers to the UX8.

ZONE	NAME	TYPE	LINK
1	CONTROLLER1	RGBW	●
2	CONTROLLER2	RGBW	●
3	CONTROLLER3	None	○
4	CONTROLLER4	None	○
5	CONTROLLER5	None	○
6	CONTROLLER6	None	○
7	CONTROLLER7	None	○
8	CONTROLLER8	None	○
9	CONTROLLER9	None	○
10	CONTROLLER10	None	○
11	CONTROLLER11	None	○

EcolocityLED.com
info@EcolocityLED.com

ECOLOCITY
LED Lighting Solutions

775-636-6060